Evaluating QC test thresholds with Excel pivot tables and charts


For an actual example, download the file called 'PIVOTCHART_DATA_QC_Hunting_AW_20140422_20190425' (sorry, it's large!)

Open the aggregated csv file. Save it as an Excel file.


Name	Date modified	Туре
DATA_QC_QB283_AW_20160412_20201006	02/04/2021 8:26 PM	Microsoft Excel C
DATA_QC_QB283_AW_20160412_20201006_Report_Aggregate	02/04/2021 8:27 PM	Microsoft Word D

Click in the upper left corner of the spreadsheet


All the cells should become highlighted (in gray)





Insert Pivot table





Click 'ok'
















Evaluate the maximum and minimum values (in this example, maximum value for water temperature).


Do the default thresholds look appropriate for your site? If not, adjust them.






Optional:

You can also put two parameters in the Values box at once, or put the same parameter in twice (e.g., water temp 2x) and select max value for one and min for the other, and both will appear in the plot.




As you create new pivot tables/charts, rename the worksheets (e.g., MaxWaterTemp)




rename the worksheets (e.g., MaxWaterTemp)
For an example, see the Excel file 'PIVOTCHART_DATA_QC_Hunting_AW_20140422_20190425'

Troubleshooting tip

If the box on the right-hand side disappears, click on the columns on the left-hand side and the right-hand box should reappear



Evaluating the Spike Test thresholds in Excel



Spike test evaluation

Create a new worksheet

Copy and paste Date, Time, Year, MonthDay, and the desired parameters into the worksheet (in this example, Water.Temp.C and Air.Temp.C)

Create a new column for each parameter (in this example, WaterSpike and Air Spike, highlighted in yellow). Enter the absolute difference formula (cell above – cell below). In this example, where the water temperature data is in Col E, you start with this formula =ABS(E2-E3) and carry it to the bottom (the next cell should read ABS(E3-E4) and so on...

Delete the value in the last row since it doesn't have another value to compare to.

Create a pivot table and column plot – see next slide


Spike test evaluation

To create the pivot table, follow the same instructions as above (see slides 3-9) except select 'Column plot' instead of 'Line plot'.


Evaluate the maximum values.

Do the default thresholds look appropriate for your site? If not, adjust them.

Sorry – these plots get to be slow and clunky because the Excel file is usually very large. But I find them helpful enough to be worth the time, at least currently.



Documentation



Documentation

We provide a 'threshold check' worksheet that you can use to document threshold changes and the basis for those changes.

Download the Excel file 'ThresholdsCheckWorksheet Template 20220117'

Reminder -

Units are important! If you change from feet to meters or °C to °F, you will need to adjust the default QC test thresholds accordingly. The user can also modify the units in the Config file.